

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21

(August 1, 2005)
Proof Test Schedule

Load Resistance Factor Design Method (LRFD)	Load Factor Design Method (LFD)
Load	Load
AL	AL
0.25FDL	0.25DL
0.50FDL	0.50DL
0.75FDL	0.75DL
1.00FDL	1.00DL
1.15FDL	1.25DL
Jack to lock-off load	1.50DL
	Jack to lock-off load

Where: AL - is the alignment load
DL - is the design load
FDL - is the factored design load